

AUTOFLOORGUARD.COM

WE CATCH IT ALL

INSTALLATION, WARRANTY AND CLEANING COMPACT, MID-SIZE & SUV/TRUCK AUTOFLOORGUARD'S

INSTALLATION

Take product out of box and layout on surface that is being covered. Make sure same area is clear of debris/items that could cause indentations and/or possible tears in fabric. Unfold product completely and understand not all wrinkles may come out because of the heat-sealed seams. We designed our product to be used **Seam Side UP!** This creates more of a tray effect to collect rain, snow, mud or other fluids. Having the seam side up provides a slight texture to the mat, making it less slippery overall. Seam side up also allows the mat to lay flatter on the garage floor. Lastly, after a huge success of testing our new Stay-Put-Corners, we have decided to make them standard in all NEW in-stock AFG inventory. Stay-Put-Corners help keep the mat in place and lay better on the ground. Please see the reverse side for further installation instructions for your Stay-Put-Corners or visit our website for an installation at <https://www.autofloorguard.com/stay-put-corners.cfm>.

AFG WARRANTY

AutoFloorGuard (AFG) warrants your AFG mat to be free from defects in material and workmanship for a period of 365 days from the date of purchase, subject to the following conditions and limitations:

CONDITIONS:

Warranty period is determined by date of purchase direct from AFG or from authorized resellers of AutoFloorGuard. (Please keep original purchase receipt)

Limitations: This warranty does not cover the following:

- Improper installation of AFG (Didn't follow instructions)
- Slight size variations in finished product compared to custom or stated size on web and/or product box due to heat-sealing of edges
- AFG is not responsible for damage from acts of nature
- Placement of the AFG on any surface that is not smooth and flat
- Use with snow chains or studded snow tires
- Burns caused by hot objects or open flames (See Warning below)
- Punctures caused by rocks and other sharp objects. (Like shovels and rakes)
- Use of solvents, chemicals and abrasive detergents to clean the AFG (Example is bleach)
- Normal wear and tear
- Discoloration of the vinyl sheeting that may occur over time from direct or indirect light
- Tire impressions made on the vinyl sheeting, which is considered normal
- Hot Tire marks/sticking on Mat. This is caused by driving on AFG while tires are hot from the road. Can cause mat to bunch up while backing up.
Solution: Cool tires prior to pulling in on; pull slightly ahead before backing up to free sticky tires.



WARRANTY FOR COMPACT, MID-SIZE & SUV/TRUCK AFG

Should a defect occur, contact AutoFloorGuard to request a Return Merchandise Number. No returns will be accepted without a Return Merchandise Number (RMA). It is the responsibility of the customer to pay for all shipping costs including insurance. Upon receipt of the returned product(s), AutoFloorGuard will either repair or replace the defective product(s) as deems necessary. Please see website for more details.

WARRANTY FOR CUSTOM AFG

Should a manufacturing defect be found in the first 90 days, contact AutoFloorGuard to discuss issue, and see how it can be resolved. No refunds will be accepted for any custom AFG units.

CAUTION:

The AFG mat is **SLIPPERY WHEN WET!** Use caution when walking or driving on AFG mat. Removal of fluids and debris is recommended daily. Also be careful not to turn wheels while on mat as this could cause damage. Also be aware that too much water and below freezing temperatures could result in ice forming around tires and cause the fabric to tear. **Warning:** FLAMMABLE, if exposed to open flames. Do not smoke or use open flame devices (including grills, fire pits, deep fryers, smokers or lanterns) on or around the AFG mat. Do not store flammable liquids (gasoline, kerosene, propane etc.) on or around the AFG mat.

CLEANING AND CARE:

A cleaner surface helps maintain longer life for AFG. For best results clean mat weekly with a soft bristle broom, mop, or squeegee. We recommend keeping AFG end close to the garage threshold and hosing the AFG with a mild kitchen detergent to remove dirt and debris. If mat is soiled with oil or other chemicals please use proper disposal, (check with your local government on disposal requirements).

STAY PUT CORNERS INSTALLATION GUIDE

Your new AutoFloorGuard (AFG) is ready to use right out of the box. However, you may wish to install the enclosed Stay-Put-Corners to enhance the performance of our containment system. Installation of Stay-Put-Corners is strongly recommended under the following conditions:

- If after unboxing your AFG you find the natural wrinkles and creases, or corners don't sit flat. It will take some time for these areas to relax.
- If you experience wind gusts lifting your AFG when pulling in or out of the garage.
- If your AFG is moved slightly from its intended position due to an occasional hot tire sticking to the dry mat.
- If your AFG moves out of position when using a squeegee or broom to sweep out accumulated liquids.

To Install Stay-Put Corners:



STEP 1

Lay the mat with the AutoFloorGuard logo facing upward.



STEP 2

Position the AFG mat on the floor where you want it; starting with the edge nearest to the garage door.



STEP 3

Mark the floor with chalk or tape (not included) around the corner edges of the AFG.



STEP 4

Wipe the floor AFG mat corners inside the position marks with the supplied alcohol wipes or use a rag with rubbing alcohol. Allow time to dry.



STEP 5

Attach each Stay-Put Corner to the mat first, then peel off the glue side tape on the opposite (floor) side. Carefully turn over the corners, press down and secure to the floor.

***Stay-Put Corners must be used with caution if you have a painted, tiled or finished garage floor as the glue may pull up any coated surface. Use at own risk and AutoFloorGuard is not liable for any floor damage if they are installed. Depending on the floor type the "Stay-Put Corners" may not adhere to your floor or last for extended period of time.