

# How To:

## Install 1/2" Poly Fittings



**Tip:** Rub a small amount of cooking oil on the inside of the 1/2" Poly for even easier installation.



Pull the collar back to expose the barb with built-in O-ring.



Push the 1/2" Poly securely onto the barb and past the built-in O-ring.



Hand tighten the collar back over the 1/2" Poly.

# What Goes First On The Faucet?

## An Installation Guide

Mister Landscaper offers a variety of solutions when it comes to connecting a system to an outdoor faucet or enhancing the functionality of that system. But in the event that you want to use all of the faucet accessories, here's a simple guide to help keep things straight. Install in this order:

- 1) Optional "Y" Fitting for hose
- 2) Electronic Water Timer (MLWT-ELEC)
- 3) Backflow Prevention Valve (MLF-31)
- 4) Pressure Regulator (MLA-58 for Micro Sprinklers or MLD-25PR for Drippers)
- 5) Filter (MLFF-41)
- 6) 1/2 in. Poly Faucet Fitting (MLF-33), which connects to 1/2 in Poly Tubing. Or the 1/4 in. Faucet Adapter (MLA-FAS), which connects to 1/4 in. Vinyl Tubing

When installed correctly, your system will function as it should and give you optimal performance.



MLFF-41

MLA-FAS

1/4 in. Vinyl Tubing

or

MLF-33

1/2 in. Poly Tubing