




BLASTER STORAGE

1. Make sure trigger lock is in locked position when storing the blaster.
2. Prior to storage, clean the blaster of any Nerf Pro Gelfire round residue that remains in the hopper feed or the barrel. Use a long soft and clean item, such as a cotton swab, to clear debris. Clean only with a damp cloth or a soft, clean, dry item.



CUSTOMIZE

HOPPER

Nerf Pro Gelfire hoppers are compatible with all Nerf Pro Gelfire blasters.

Blasters each sold separately, subject to availability.



BARREL ATTACHMENT POINT

Barrel not included.

PRODUCT AND COLORS MAY VARY.

NERF and HASBRO and all related trademarks and logos are trademarks of Hasbro, Inc. © 2023 Hasbro. Hasbro, Pawtucket, RI 02861-1059 USA. US TEL. 1-800-255-5516 F7979

PN00081947

NERF PRO GEL FIRE LEGION

14+

TO AVOID EYE INJURY:

WARNING :

Do not aim at eyes or face. Use of eyewear always required for players and people within range. Use only official NERF GelFire Rounds. Use only clean tap water to hydrate rounds. Do not freeze or modify rounds. Do not modify blaster. Impact from rounds may cause temporary marks on skin. Ages 14 and up. This is not a toy. Read instructions before use for important safety information.

WARNING :

COMPLY WITH ALL LAWS. Check to ensure the use and possession of this product is allowed where you are intending to use it, as using, displaying, transporting, or carrying this product may be prohibited by law or regulation in certain locations, such as schools, airports, government property, and high-density areas. Do not aim or blast at bystanders, animals, moving vehicles, or others' property. Do not alter this product to make it look like a firearm. Such alteration is dangerous and could be a crime and/or create confusion by law enforcement or others that it is a firearm.

DO NOT EAT. KEEP AWAY FROM PETS. ROUNDS MAY STAIN.



1. HYDRATE ROUNDS

Open 1 packet and pour rounds into container of clean tap water. It is recommended to use at least 0.5 gallon/2 liters of water per 5,000 rounds. If you want to hydrate only some of the rounds in a packet and save some rounds for later, use the same amount of water. **More water than recommended will not impact hydration: It is not possible to overhydrate the rounds or grow them too large to function in the blaster.** Make sure rounds are fully submerged in water.

Allow rounds to remain in container for about 3-4 hours to be fully hydrated.





ROUND STORAGE

Discard any unused hydrated rounds.

2. ATTACH HOPPER

Remove cap from hopper and hold it with opening facing up. Fill hopper with hydrated rounds. Drain ALL water from hopper.

Holding blaster upside down, twist hopper onto blaster with a 1/4 turn to lock it in place. Make sure hopper is securely attached. Turn blaster right side up.




3. FIRE




Wear the included protective eyewear when you or anyone else nearby is using a Nerf Pro Gelfire blaster.

Unlock Trigger




Single Fire

1 Pull priming handle back and release; handle will automatically spring back to original position.



2 Pull trigger to fire 1 round.



Slam Fire

With Slam Fire, you keep the trigger held down as you repeatedly pull/release the handle to fire each round.

