

# XDMBT17

# **Quick Start Guide**

**Digital Media Receiver** 



To download the complete, model-specific manual, please visit www.dualav.com/support/manuals.php or call 1-866-382-5476, 9AM-5PM EST (Monday-Friday).

## Installation

- Before You Start Consult a qualified technician for instructions. Dual always recommends nrofessional installation
- Disconnect negative battery terminal.
   Insert the removal keys, and remove the mounting sleeve from the head unit.

### Installation Process

- Carefully remove the existing head unit. (if applicable) . Connect wiring harness. Consult a qualified technician if you are unsure.
- 3. Mount the head unit using the mounting sleeve.
  4. Connect wiring harness and antenna. Test the head unit for correct operation.
  5. Slide the radio into the mounting sleeve to secure the radio.
  4. Separation consists along the sleep the secure the radio.
- 6. Snap silicon caps into place.

**Wiring Connections**The chart below the connection for each wire in the wiring harness.

| Color        | Connection                  |  |  |
|--------------|-----------------------------|--|--|
| Red          | 12V Ignition / Accessory    |  |  |
| Yellow       | 12V Battery / Memory        |  |  |
| Black        | Ground                      |  |  |
| Blue         | Power Antenna / Amp Turn-on |  |  |
| White        | Left Front (+)              |  |  |
| White/Black  | Left Front (-)              |  |  |
| Gray         | Right Front (+)             |  |  |
| Gray/Black   | Right Front (-)             |  |  |
| Green        | Left Rear (+)               |  |  |
| Green/Black  | Left Rear (-)               |  |  |
| Violet       | Right Rear (+)              |  |  |
| Violet/Black | Right Rear (-)              |  |  |


| Tip:                              |
|-----------------------------------|
| When a suitable ground wire is    |
| not present in the vehicle wiring |
| harness, connect the black ground |
| wire to the vehicle chassis.      |

| Fuse:<br>When replacing the fuse, make |
|--|
| sure new fuse is the correct type      |
| and amperage. Using an incorrect       |
| fuse could damage the radio.           |


### Mounting the Head Unit: Typical DIN mounting

## Step 1:

Insert the mounting sleeve into the installation kit or dashboard.




Step 2: Bend multiple mounting tabs around the mounting sleeve until the mounting sleeve is secure.



### Step 3:

Connect all wiring harnesses and slide the head unit into the mounting sleeve until it clicks into place.



## Step 4:

Remove the plastic caps and use the removal keys to remove the unit.



## General Operation

|                  | deficial operation  |
|------------------|---|
| Power On/Off     | Press the $\ensuremath{\mathcal{O}}$ button to turn the unit on. Press $\ensuremath{\mathcal{O}}$ again to turn unit off. |
| Changing Modes   | Press <b>MODE</b> to select between Radio, USB,<br>Bluetooth, AUX.<br>Modes of operation are shown in the display.        |
| Volume           | Adjust volume using volume knob.  |
| Mute             | Press শ্লুপ্ত to silence the audio. Press শ্লুপ্ত again to resume<br>listening at the previously selected volume.         |
| Auxiliary Inputs | Insert a 3.5mm cable in the units front AUX port.   |

With the unit on, long press  $\ensuremath{\text{DISP}}$  to display clock time. Press and Setting the Clock hold DISP until the hours or minutes begin to flash, then release. Rotate the volume knob to adjust the time. Long press DISP to finish the clock setting

Display Press DISP to toggle display between various displayed information Audio / Menu Press volume knob momentarily to select between the

Press the RESET button to reset the unit back to the factory settings if abnormal operation occurs. The reset button is located on the front panel.

audio functions. Press and hold volume knob for more than two seconds to select between the menu functions Rotate the volume knob left/right to adjust or activate the

To download the complete Owner's Manual for your radio. please visit www.dualav.com/support/manuals.php.

## AM/FM Tuner Operation

|                                     | AM/FM Tuner Operation   |                             | USB Operation  |
|-------------------------------------|---|-----------------------------|--|
| Seek Tuning                         | Press TUNE ◀◀ or TUNE ▶▶ to seek to previous or next strong station.  | Playing MP3 Files           | To play MP3 files, insert a USB device containing MP3 files.   |
| Manual Tuning Pre<br>tun<br>to r    | Press and hold the TUNE ◀◀ or TUNE ▶▶ to enter manual tuning mode. Then press TUNE ◀◀ or TUNE ▶▶ momentarily  | Track Select                | Press TUNE ►► to skip to the beginning of the next song.  Press TUNE ◄◄ to skip to the beginning of the previous song.                     |
|                                     | to move radio frequency down or up one step at a time.  Press and hold TUNE   or TUNE   to advance quickly.   | Fast Forward and<br>Reverse | Press and hold <b>TUNE</b> ►► or <b>TUNE</b> ◀◀ to fast forward or reverse a track.  |
| and AM2 bands.<br>for each band, er | Press BAND to select between FM1, FM2, FM3, AM1<br>and AM2 bands. Up to six presets can be programmed   | Pause                       | Press ►/ II to temporarily stop playback. Press ►/ III again to resume playback.   |
|                                     | for each band, enabling up to 18 FM stations and 12 AM stations to be stored in memory.   | Folder Access               | Folder can be found by pressing Folder Up or Folder Down.<br>About 1 second after the folder name is displayed, the first                  |
| a<br>h<br>s                         | Up to 18 FM and 12 AM stations can be stored. To store a station, select the desired band and station. Press and hold the desired preset button (1-6) for more than two seconds. When stored, the preset number will appear in the display. | Donast                      | file under the selected folder will be displayed and playback.   |
|                                     |   | Repeat                      | Press RPT to toggle between RPT ALL and RPT ONE.  RPT ALL - Plays all tracks on USB device. RPT ONE - Continuously repeats selected track. |
| Recalling Presets                   | Preset stations can be recalled any time by pressing the corresponding preset button.   | Random                      | Press <b>RDM</b> to play tracks in random order, press again to cancel the <b>RDM</b> function.  |
| Auto store                          | Press and hold MENU for more than 2 seconds , then press DISP t<br>18 FM stations and 12 AM stations automatically.   | to store Intro              | Press <b>INT</b> to plays first 10 seconds of each track, press again to cancel the <b>INT</b> function.                                   |
| Preset Scan                         | Touch PS to recall each preset station that has been stored in memory for each band. (Available with the Dual Smart Remote App only)  | n                           |  |
|                                     |   |                             |  |
|                                     |   |                             |  |

To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php.

# To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php.

## Bluetooth® Operation

| Preparation | Before using a Bluetooth device, it must be paired an |
|-------------|---|
|             | connected. Ensure that Bluetooth is activated on your |
|             | device before beginning the pairing process.          |

# Pairing a New Device

The head unit broadcasts the pairing signal constantly when no devices are connected. Complete the pairing sequence from your Bluetooth device. Refer to the owner's manual for your device for more details.

The device name is "Dual Media Player" The Bluetooth passcode is "1234"

Note: If passcode "1234" does not pair your device to the receiver, use passcode "0000"

Note: The head unit can be in any mode of operation

**Streaming Audio** 

The head unit supports A2DP wireless streaming audio from a Bluetooth mobile device directly to your head unit. The following functions can be used to control the music

- Press >> to skip to the next available audio track.
- Press ◀◀ to skip to the previous audio track.
- Press >/ III to toggle between play and pause during playback.

# **APP Operation**

The Dual Smart App is the ultimate wireless remote control for your XDM17BT receiver. You can download Dual Smart app from Apple App Store or Google Play Store and install it on your smartphone or tablet.

Please scan the following QR code to download Dual iPlug P2 App to



## **Voice Activation Operation**

Bluetooth should be paired between your smartphone and the receiver Press the voice activation button and the receiver will switch into Bluetooth mode, This will activate Siri® or Google Assistant™ on your smartphone. You will need to manually switch back to the previous or desired mode once this operation is terminated.

# **Limited One-Year Warranty**

This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Dual Electronics Corp. warrants this product to the original purchaser to be free from defects in material and workmanship for a period of one year from the date of the original purchase. (Note that select marine products carry a 2-year warranty. Please visit www.dualav.com for details.) Dual Electronics Corp. agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original

Who is covered? This warranty is extended to the original retail purchaser for products purchased and used in the U.S.A.

What is covered? This warranty covers all defects in material and workmanship what is covered: This warrainy covered: installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair or failure to follow instructions supplied with the product, or damage occurring during return ship of the product.

- 1. Before you call for service, check the troubleshooting guide in your owner's
- manual. A slight adjustment of any custom controls may save you a service call.

  If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized service
- 3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipment.
- 4. For more information and for the location of the nearest authorized service center please contact us toll-free at 1-866-382-5476 or by email at cs@dualav.com

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental or consequential damages.

. . . . . . . . . . . . . . . To download the complete Owner's Manual for your radio, please visit www.dualav.com/support/manuals.php

## **FCC Compliance**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This reasonable protection against narmful interference in a residential installation. This equipment generates, uses and can radialter radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
  Increase the separation between the equipment and receiver.
  Connect the equipment into an outlet on a circuit different from that to which the
- Consult the dealer or an experienced radio technician for help



©2019 Dual Electronics Corp. All rights reserved. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Siri and Apple are registered trademarks owned by Apple Inc.
Google Assistant and Android are trademarks owned by Google LLC. Other trademarks and trade names are those of their respective owners