

# P280236




# GARDEN & GROW GREENHOUSE PLAYHOUSE



**OBSTACLE FREE SAFETY ZONE** - 5 x 4.9 x 3.2 m (16 ft 4.9 in x 16 ft 0.9 in x 10 ft 6 in) area requires Protective Surfacing.

**CAPACITY** - 6 Users Maximum, Ages 3 - 10; Weight Limit 50 kg ( 110 lb) per child.

**RESIDENTIAL HOME USE ONLY.** Not intended for public areas such as multi-unit residences, schools, churches, nurseries, day cares or parks.



**IMPORTANT: RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.**



## INSTALLATION AND OPERATING INSTRUCTIONS

**FOR 24/7 ONLINE PARTS REPLACEMENT**

**kidkraft.com**

Backyard Kids, LLC DBA KidKraft  
 317 S. Main St.  
 Ann Arbor, MI 48104

customerservice@kidkraft.com  
 1.800.933.0771  
 972.385.0100

9400236

Rev 01/19/2026

### **⚠ WARNING**

To reduce the risk of serious injury or death, please read and follow these instructions. Keep and refer to instructions as needed and pass along to any future owners of this item.

## **Congratulations on purchasing a KidKraft product!**


**Our items are made of high-quality,  
durable Cunninghamia Lanceolata wood  
from the cypress family.**

**Lumber from these trees are known for  
their light weight and excellent strength.  
The porosity of this wood allows the  
moisture to absorb and evaporate in the  
fibers, resisting rot and bugs.**

**Engineered for great play, our products  
also go through extensive testing for safety.**

**Plus, our team has developed a series of  
proprietary methods for a simpler, more  
organized assembly. Less build time and  
more play time is our motto!**

**However, during assembly if you have any  
questions or concerns, please reach out.  
Our Customer Service can help with missing  
parts, instructions or maintenance.**



**NOTE:** Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.

## Warnings and Safe Play Instructions

**CONTINUOUS ADULT SUPERVISION REQUIRED.** Most serious injuries and deaths on playground equipment have occurred while children were unsupervised! Our products are designed to meet mandatory and voluntary safety standards. Complying with all warnings and recommendations in these instructions will reduce the risk of serious or fatal injury to children using this play system. Go over the warnings and safe play instructions regularly with your children and make certain that they understand and follow them. Remember on-site adult supervision is required for children of all ages.

|  <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>CHOKING HAZARD/SHARP EDGES &amp; POINTS</b><br/>Adult assembly required. This product contains small parts and parts with sharp edges and points. Keep parts away from children until fully assembled.</p> <p><b>STRANGULATION HAZARD</b></p> <ul style="list-style-type: none"> <li>• <b>NEVER</b> allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this playhouse or to attach these items to the playhouse.</li> <li>• <b>NEVER</b> allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using this playhouse.</li> <li>• <b>NEVER</b> allow children to wear bike or sport helmets when using this playhouse.</li> </ul> | <p>Failure to prohibit these items, even helmets with chin straps, increases the risk of serious injury and death to children from entanglement and strangulation.</p> <p><b>TIP OVER HAZARD</b><br/>Choose a level location for the equipment. This can reduce the likelihood of the playhouse tipping over and loose-fill surfacing materials washing away during heavy rains.</p> <p><b>DO NOT</b> allow children to play on the playhouse until the assembly is complete.</p> <p><b>PLACEMENT</b><br/>Place the toy on a level surface at least 2 m (6.5 ft) from any structure or obstruction such as fences, garages, house, overhanging branches, laundry or electrical wires.</p> |


## **WARNING** – Safe Play Instructions

- |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>✓ Dress children with well fitting and full foot enclosing footwear.</li> <li>✓ Check for splintered, broken or cracked wood; missing, loose, or sharp edged hardware. Replace, tighten and or sand smooth as required prior to playing.</li> <li>✓ Replace defective parts in accordance with manufacturer's instructions.</li> <li>✓ Orientate slide such that it gets the least amount of exposure to the sun.</li> </ul> | <ul style="list-style-type: none"> <li>✗ Do not allow children to wear open toe or heel footwear like sandals, flip-flops or clogs.</li> <li>✗ Do not permit climbing on equipment when it is wet.</li> <li>✗ Do not permit rough play or use of equipment in a manner for which it was not intended. Standing or climbing on or jumping from the roof.</li> </ul> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### Instructions for Proper Maintenance

Your KidKraft Play System is designed and constructed of quality materials with your child's safety in mind. As with all outdoor products used by children, it will weather and wear. To maximize the enjoyment, safety and life of your Playhouse, it is important that you, the owner, properly maintain it. Failure to follow maintenance directions below can cause the swing set to overturn or otherwise become a hazard to children.

#### Check the following at the beginning of the play season:

|                                                                                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>HARDWARE:</b></p> <ul style="list-style-type: none"> <li>✓ Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.</li> <li>✓ Inspect and tighten all hardware. On wood assemblies <b>DO NOT OVER-TIGHTEN</b> as to cause crushing and splintering of wood.</li> <li>✓ Check for sharp edges or protruding screw threads, add washers if required.</li> </ul> |  <p><b>WOOD PARTS:</b></p> <ul style="list-style-type: none"> <li>✓ Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal.</li> <li>✓ Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.</li> </ul> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

#### Check twice a month during play season:

|                                                                                                                                                                                                                        |                                                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| <p><b>HARDWARE:</b></p> <ul style="list-style-type: none"> <li>✓ Inspect for tightness. Must be firmly against, but not crushing the wood. <b>DO NOT OVER-TIGHTEN.</b> This will cause splintering of wood.</li> </ul> | <ul style="list-style-type: none"> <li>✓ Check for sharp edges or protruding screw threads. Add washers if required.</li> </ul> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|

**If you dispose of your playhouse:** Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.

# Keys to Assembly Success

## Tools Required

|                                                                                                                                                  |                                                                                                                                                                  |                                                                                                                             |                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>• Carpenters Level</li> <li>• Carpenters Square</li> <li>• Claw Hammer</li> <li>• Tape Measure</li> </ul> | <ul style="list-style-type: none"> <li>• #1 Phillips, #2 Robertson and Screwdriver</li> <li>• Ratchet with extension</li> <li>11 mm (7/16 in) sockets</li> </ul> | <ul style="list-style-type: none"> <li>• Open End Wrench</li> <li>• Standard or Cordless Drill</li> <li>• Pencil</li> </ul> | <ul style="list-style-type: none"> <li>• Safety Glasses</li> <li>• Adult Helpers</li> </ul> |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|



## Part Identification Key

On each page, you will find the parts and quantities required to complete the assembly step illustrated on that page. Here is a sample.

|           |             |                                           |
|-----------|-------------|-------------------------------------------|
| <b>2X</b> | <b>1008</b> | <b>50 x 100 x 2108 mm (2 x 4 x 83 in)</b> |
| Quantity  | Key Number  | Part Size                                 |


## Symbols

Throughout these instructions symbols are provided as important reminders for proper and safe assembly.

|                                                                                                                                                                                                                         |                                                                                                   |                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.</p>  |                                                                                                   | <p>Check that set or assembly is properly level before proceeding.</p> <p>Use Level</p>                                                                              |
| <p>Use Help</p>                                                                                                                        | <p>Use Help</p>  | <p>Where this is shown, 2 or 3 people are required to safely complete the step. To avoid injury or damage to the assembly make sure to get help!</p>                                                                                                    |
| <p>Measure Distance</p>                                                                                                               | <p>Check that assembly is square before tightening bolts.</p>                                     | <p>Square Assembly</p>                                                                                                                                                |
| <p>Use a measuring tape to assure proper location.</p>                                                                                                                                                                  |                                                                                                   | <p>Pre-drill 3 mm (1/8 in) Bit</p>  <p>Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.</p>                                          |
|                                                                                                                                                                                                                         |                                                                                                   | <p>Tighten Bolts</p>  <p>This indicates time to tighten bolts, but not too tight! Do not crush the wood. This may create splinters and cause structural damage.</p> |

## CAUTION – Protrusion Hazard

Once the assembly is tightened, watch for exposed threads. If a thread protrudes from the T-Nut, remove the bolt and add washers to eliminate this condition. Extra washers have been provided for this purpose.




## Proper Hardware Assembly

Lag screws require drilling pilot holes to avoid splitting wood. Only a flat washer is required. For ease of installation liquid soap can be used on all lag-type screws.

For bolts, tap T-Nut into hole with hammer. Insert the hex bolt through lock washer first then flat washer then hole. Because the assemblies need to be squared do not completely tighten until instructed. Pay close attention to diameter of the bolts. 7.9 mm (5/16 in) is slightly larger than 6.3 mm (1/4 in).

Note: Wafer head bolts with blue lock tight or a bolt with a Ny-Lok nut do NOT require a lock washer.



## About Our Wood

KidKraft Premium Play Systems uses only premium playset lumber, ensuring the safest product for your children's use. Although we take great care in selecting the best quality lumber available, wood is still a product of nature and susceptible to weathering which can change the appearance of your set.

### What causes weathering? Does it affect the strength of my Play System?

One of the main reasons for weathering is the effects of water (moisture); the moisture content of the wood at the surface is different than the interior of the wood. As the climate changes, moisture moves in or out of the wood, causing tension which can result in checking and or warping. You can expect the following due to weathering. These changes will not affect the strength of the product:

1. **Checking** is surface cracks in the wood along the grain. A post 10.1 x 10.1 cm (4 x 4 in) will experience more checking than a board 2.5 x 10.1 cm (1 x 4 in) because the surface and interior moisture content will vary more widely than in thinner wood.
2. **Warping** results from any distortion (twisting, cupping) from the original plane of the board and often happens from rapid wetting and drying of the wood.
3. **Fading** happens as a natural change in the wood color as it is exposed to sun-light and will turn a grey over time.

### How can I reduce the amount of weathering to my Play System?

At the factory we have coated the wood with a water repellent or stain. This coating decreases the amount of water absorption during rain or snow thus decreasing the tension in the wood. Sunlight will break down the coating, so we recommend applying a water repellent or stain on a yearly basis (see your local stain and paint supplier for a recommended product).

Most weathering is just the normal result of nature and will not affect safe play and enjoyment for your child. However if you are concerned that a part has experienced a severe weathering problem please call our consumer relations department for further assistance.

**Complete and mail registration card to receive important product notifications and assure prompt warranty service.**

# KidKraft Limited Warranty

## MISSING OR DAMAGED PARTS:

KidKraft will replace any parts within 90 days from date of purchase found to be missing from or damaged in the original packaging. See Fig.1

|        |                                                                   |                                                      |
|--------|-------------------------------------------------------------------|------------------------------------------------------|
| Fig. 1 | <u>Product Age (All Parts)</u><br>0-90 Days from date of purchase | <u>Consumer Pays</u><br>\$0 for Part + Free Shipping |
|--------|-------------------------------------------------------------------|------------------------------------------------------|

## DEFECTS IN MATERIAL AND WORKMANSHIP:

KidKraft warrants that this product is free from defects in materials and workmanship for a period of one (1) year from the original date of purchase (dated sales receipt and/or product registration is required). This one (1) year warranty covers all parts including wood, hardware, and all accessories (Such as swings, rides, and slides). See Fig. 2

|        |                                                     |                                                      |
|--------|-----------------------------------------------------|------------------------------------------------------|
| Fig. 2 | <u>Product Age (All Parts)</u><br>91 Days to 1 Year | <u>Consumer Pays</u><br>\$0 for Part + Free Shipping |
|--------|-----------------------------------------------------|------------------------------------------------------|

## WOOD ROT, DECAY, AND INSECT DAMAGE:

All wood carries a five (5) year warranty against rot, decay, and insect damage (dated sales receipt and/or product registration is required). Refer to the schedule below for charges associated with replacement of wood parts under this **Limited Warranty**. See Fig. 3

|        |                                                                                               |                                                                                                                                                  |
|--------|-----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Fig. 3 | <u>Product Age (Wood Parts)</u><br>0 Days to 1 Year<br>After 1 Year to 5 Year<br>Over 5 Years | <u>Consumer Pays</u><br>\$0 for Part + Free Shipping<br>\$0 for Part + Shipping & Handling<br>100% for Part (if available) + Shipping & Handling |
|--------|-----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|

This warranty applies to the original owner and registrant and is non-transferable. Regular maintenance is required to ensure the integrity of this product. Failure by the owner to maintain the product according to the maintenance requirements may void this warranty.

This Limited Warranty does NOT cover:

- Any inspection cost
- Labor and/or costs for replacement of any defective item(s), including but not limited to, professional installer costs
- Incidental or consequential damages, including but not limited to, as a result of set relocation, move and/or reinstall
- Cosmetic defects which do not affect performance or integrity of a part or the entire product
- Vandalism, improper use or installation, or acts of nature, including but not limited to, high winds, fire, and flood
- Minor twisting, warping, checking, or any natural occurring properties of wood that do not affect performance or integrity.
- Any KidKraft product purchased, including but not limited to, a non-approved retailer, auction houses, second-hand, and as-is clearance items.


KidKraft products have been designed for safety and quality. Modifications made to the original product may damage the structural integrity of the unit leading to failure and possible injury. KidKraft cannot assume any responsibility for the modified products. Furthermore, modifications void all warranties.

This product is warranted for **RESIDENTIAL USE ONLY**. Under no circumstance should a KidKraft product be used in public settings such as schools, churches, playgrounds, parks, home and professional day cares and the like. Such use may lead to product failure and potential injury. Public use will void this warranty. KidKraft disclaims all other representations and warranties of any kind, express or implied.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.


## Part Identification (Reduced Size)

1x - **2715** - 25.4 x 63.5 x 254 mm - 3772715




1 x 2 1/2 x 10 in

2x - **1089** - 25.4 x 50.8 x 228.6 mm - 38108977



1 x 2 x 9 in

1x - **1090** - 15.9 x 114.3 x 535.8 mm - 38109077




5/8 x 4 1/2 x 21 1/16 in

1x - **1092** - 25.4 x 25.4 x 362 mm - 38109277



1 x 1 x 14 1/4 in

4x - **1094** - 15.9 x 130 x 279.4 mm - 38109477



5/8 x 5 1/8 x 11 in

1x - **1096** - 25.4 x 50.8 x 254 mm - 38109656




1 x 2 x 10 in

2x - **1100** - 25.4 x 25.4 x 478.9 mm - 38110073




1 x 1 x 18 7/8 in

1x - **1101** - 25.4 x 88.9 x 308.1 mm - 38110173




1 x 3 1/2 x 12 1/8 in

2x - **1102** - 15.9 x 130 x 358.9 mm - 38110277



5/8 x 5 1/8 x 14 1/8 in

2x - **1088** - 15.9 x 101.6 x 246.6 mm - 38108877




5/8 x 4 x 9 11/16 in

6x - **0998** - 25.4 x 50.8 x 50.8 mm - 38099877



1 x 2 x 2 in

2x - **1091** - 15.9 x 136 x 588 mm - 38109177




5/8 x 5 3/8 x 23 1/8 in

10x - **1093** - 25.4 x 50.8 x 88.9 mm - 38109377




1 x 2 x 3 1/2 in

1x - **1095** - 15.9 x 114.3 x 400.1 mm - 38109577




5/8 x 4 1/2 x 15 3/4 in

1x - **1097** - 25.4 x 50.8 x 198.9 mm - 38109756




1 x 2 x 7 13/16 in

2x - **1099** - 25.4 x 25.4 x 308.1 mm - 38109973




1 x 1 x 12 1/8 in

2x - **1103** - 25.4 x 25.4 x 320.9 mm - 38110377




1 x 1 x 12 5/8 in

1x - **1103** - 25.4 x 25.4 x 320.9 mm - 38110356



1 x 1 x 12 5/8 in


2x - **1108** - 15.9 x 85.7 x 184.2 mm - 38110877



5/8 x 3 3/8 x 7 1/4 in


## Part Identification (Reduced Size)

2x - **1104** - 31.8 x 79.4 x 667 mm - 38110477




1 1/4 x 3 1/8 x 26 1/4 in

2x - **1105** - 31.8 x 79.4 x 667 mm - 38110577




1 1/4 x 3 1/8 x 26 1/4 in

2x - **1106** - 31.8 x 31.8 x 920.1 mm - 38110677




1 1/4 x 1 1/4 x 36 1/4 in

2x - **1107** - 25.4 x 50.8 x 939.7 mm - 38110777




1 x 2 x 37 in

1x - **1123** - 15.9 x 85.7 x 168.3 mm - 38110877




5/8 x 3 3/8 x 6 5/8 in

1x - **1124** - 15.9 x 85.7 x 168.3 mm - 38110877



5/8 x 3 3/8 x 6 5/8 in

1x - **1109** - 25.4 x 82.6 x 939.8 mm - 38110977




1 x 3 1/4 x 37 in

1x - **1110** - 25.4 x 55.5 x 938.2 mm - 38111077




1 x 2 1/4 x 36 15/16 in

2x - **1111** - 25.4 x 44.5 x 977.9 mm - 38111177




1 x 1 3/4 x 38.5 in

1x - **1112** - 25.4 x 50.8 x 650.8 mm - 38111277




1 x 2 x 25 5/8 in

1x - **1113** - 25.4 x 50.8 x 618.2 mm - 38111377



1 x 2 x 24 5/16 in


2x - **1114** - 25.4 x 50.8 x 938.2 mm - 38111477




1 x 2 x 36 15/16 in

## Part Identification (Reduced Size)


2x - **1115** - 15.9 x 76.2 x 317.5 mm - 38111577




4x - **1117** - 15.9 x 76.2 x 269.2 mm - 38111777




1x - **1119** - 31.8 x 50.8 x 387.1 mm - 38111977




1x - **1121** - 15.9 x 38.1 x 206.4 mm - 38112177




2x - **1116** - 15.9 x 76.2 x 355.6 mm - 38111677




1x - **1118** - 25.4 x 50.8 x 76.2 mm - 38111877



1x - **1120** - 15.9 x 34.9 x 101.6 mm - 38112077




2x - **1122** - 15.9 x 38.1 x 133.4 mm - 38112277




1x - **0938** - 50.8 x 365.1 x 372.3 mm  
- 378093877

2 x 14 3/8 x 14 5/8 in




1x - **0939** - 31.8 x 387.4 x 400 mm  
- 378093977

1 1/4 x 15 1/4 x 15 3/4 in




1x - **0940** - 25.4 x 203.2 x 609.6 mm  
- 378094077

1 x 8 x 24 in




2x - **0941** - 34.9 x 203.2 x 152.4 mm  
- 378094177

1 3/8 x 8 x 6 in




1x - **0942** - 50.8 x 365.1 x 372.3 mm  
- 378094277

2 x 14 3/8 x 14 5/8 in




1x - **0943** - 41.3 x 76.2 x 533.4 mm  
- 378094356

1 5/8 x 3 x 21 in




## Part Identification (Reduced Size)


1x - **0944** - 35 x 279.4 x 990.6 mm  
- 378094456  
1 3/8 x 11 x 39 in




1x - **0934** - 35 x 279.4 x 990.6 mm  
- 378093456  
1 3/8 x 11 x 39 in




1x - **0936** - 25.4 x 990.6 x 990.6 mm  
- 378093656  
1 x 39 x 39 in




1x - **0937** - 35 x 958.9 x 990.6 mm  
- 378093756  
1 3/8 x 37 3/4 x 39 in



1x - **0935** - 35 x 958.9 x 990.6 mm  
- 378093556  
1 3/8 x 37 3/4 x 39 in



## Part Identification (Reduced Size)



1x - 3332609



1x - 9320888STGY



1x - 9320889STGY




1x - 9320889RD



3x - P-U-510-STGY



1x - 9321691



2x - 9200147




8x - 9340710



4x - 9200770



1x - 3750000



1x - 9207711



1x - 9207713



1x - 9320371




4x - 9320157



1x - 3340023




1x - 9340031



4x - 9341928



2x - 9340029




2x - 9200768




1x - 9200769



1x - 9340730




1x - 9200767



# Hardware Identification (Actual Size)


6 x (S5) - #8 x 1/2 in - 52437502  
12.7 mm




25 x (S0) - #8 x 7/8 in - 52937505  
22.2 mm



112 x (S37) - #7 x 5/8 in - 52437009  
15.9mm




32 x (S39) - #5 x 3/4 in - 52017903  
19 mm



12 x (S41) - #8 x 7/8 in - 52047505  
22.2 mm




16 x (S20) - #8 x 1-3/8 in - 52047516  
34.9mm




106 x (S1) - #8 x 1-1/8 in - 52047514  
28.6 mm




46 x (S15) - #8 x 1-3/4 in - 52047513  
44.5 mm




6 x (S2) - #8 x 1-1/2 in - 52047512  
38.1 mm



1 x (D4) - #2 x 2 in (50.8 mm) - 9200014



16 x (S11) - #8 x 2 in - 52047520  
50.8 mm



1x - 1/8 x 3 in (3.2 x 76.2 mm) - (9300183)



27 x (S3) - #8 x 2-1/2 in - 52047522  
63.5mm




## 1 Inventory Parts - Read This Before Starting Assembly



Inventory should be completed before starting installation. KidKraft will not cover costs of any additional installation trip due to missing or damaged pieces.

- A. This is the time for you to inventory all your hardware, wood and accessories, referencing the parts identification sheets. This will assist you with your assembly.
- The wood pieces will have the key number stamped on the ends of the boards. Organize the wood pieces by step, as per the key numbering system below.



- B. Read the assembly manual completely, paying special attention to ANSI warnings, notes, and safety/maintenance information on pages 1 - 6.

**If there are missing or damaged pieces,  
please contact the KidKraft Consumer Engagement team  
before going back to the retailer.**


## Request Replacement Parts 24/7

You can request replacement parts for this product 24 hours a day / 7 days a week:


**Outdoor Swingsets and Playhouse Parts Ordering**

**<https://parts.kidkraft.com/>**

If you have assembly or product questions, please refer to the front cover for direct contact information for our Consumer Engagement team.



Make sure the assembly is square



#### Wood Parts

- 1 x **0936** 25.4 x 990.6 x 990.6 mm (1 x 39 x 39 in)  
 1 x **0935** 35 x 958.9 x 990.6 mm (1 3/8 x 37 3/4 x 39 in)


#### Hardware

- 8 x **S39** #5 x 19 mm (#5 x 3/4 in)  
 3 x **S37** #7 x 15.9 mm (#7 x 5/8 in)

#### Other Parts

- 2 x **9340710**  
 1 x **9200770**



3




Make sure the assembly is square




Rotated View



Rotated View



Rotated View



**Wood Parts**

1 x 0937 35 x 958.9 x 990.6 mm (1 3/8 x 37 3/4 x 39 in)

**Hardware**

8 x S39 #5 x 19 mm (#5 x 3/4 in)

3 x S37 #7 x 15.9 mm (#7 x 5/8 in)

**Other Parts**

2 x 9340710

1 x 9200770





**KidKraft**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)





[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

4

Make sure the  
assembly is square



Rotated View



#### Wood Parts

1 x 0944 35 x 279.4 x 990.6 mm (1 3/8 x 11 x 39 in)

#### Hardware

8 x S39 #5 x 19 mm (#5 x 3/4 in)

3 x S5 #8 x 12.7 mm (#8 x 1/2 in)

#### Other Parts

2 x 9340710

1 x 9200770





**KidKraft**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)





[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

5

Make sure the  
assembly is square



Rotated View



#### Wood Parts

1 x 0934 35 x 279.4 x 990.6 mm (1 3/8 x 11 x 39 in)

#### Hardware

8 x S39 #5 x 19 mm (#5 x 3/4 in)

3 x S5 #8 x 12.7 mm (#8 x 1/2 in)

#### Other Parts


2 x 9340710

1 x 9200770




kidkraft.com

customerservice@kidkraft.com  
1.800.933.0771  
972.385.0100





Underneath View

**Hardware**

8 x (S0) #8 x 22.2mm (#8 x 7/8 in)

**Other Parts**

1 x 9200767





**Wood Parts**



1 x 0943 41.3 x 76.2 x 533.4 mm (1 5/8 x 3 x 21 in)

**Hardware**

4 x S0 #8 x 22.2mm (#8 x 7/8 in)

**Wood Parts**1 x **0939** 31.8 x 387.4 x 400 mm (1 1/4 x 15 1/4 x 15 3/4 in)**Hardware**2 x **S37** #7 x 15.9 mm (#7 x 5/8 in)**Other Parts**1 x **9207711**
**KidKraft®**  
 MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)
[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
 1.800.933.0771  
 972.385.0100




#### Hardware

2 x  #7 x 15.9 mm (#7 x 5/8 in)

#### Other Parts


1 x  9207713

**Hardware**

2 x (S37) #7 x 15.9 mm (#7 x 5/8 in)

**Other Parts**


1 x 9320371

**Hardware**

6 x (S37) #7 x 15.9 mm (#7 x 5/8 in)

**Other Parts**

2 x 9200147





#### Wood Parts

1 x **1095** 15.9 x 114.3 x 400.1 mm (5/8 x 4 1/2 x 15 3/4 in)

#### Hardware

3 x **(S20)** #8 x 34.9 mm (#8 x 1-3/8 in)



**Wood Parts**

2 x 0998 25.4 x 50.8 x 50.8 mm (1 x 2 x 2 in)


**Hardware**

2 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)


2 x S1 #8 x 28.6 mm (#8 x 1-1/8 in)



Outside View



**Hardware**

6 x (S37) #7 x 15.9 mm (#7 x 5/8 in)



Close door and vertically center magnetic catch to catch plate to assemble

DO NOT overtighten







#### Wood Parts

1 x 2715 25.4 x 63.5 x 254 mm (1 x 2 1/2 x 10 in)

#### Hardware

3 x S11 #8 x 50.8 mm (#8 x 2 in)



2 x S37 #7 x 15.9 mm (#7 x 5/8 in)

**Wood Parts**

8 x 1093 25.4 x 50.8 x 88.9 mm (1 x 2 x 3 1/2")

**Hardware**

8 x S3 #8 x 63.5 mm (#8 x 2-1/2")




#### Wood Parts

4 x **1094** 15.9 x 130 x 279.4 mm (5/8 x 5 1/8 x 11 in)

#### Hardware

16 x **S1** #8 x 28.6mm (#8 x 1-1/8 in)




#### Wood Parts


- 1 x 0940 25.4 x 203.2 x 609.6 mm (1 x 8 x 24 in)  
 2 x 0941 34.9 x 203.2 x 152.4 mm (1 3/8 x 8 x 6 in)

#### Hardware


- 6 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)





Outside View



Inside View

**Hardware**

4 x (S15) #8 x 44.5 mm (#8 x 1-3/4 in)

**Wood Parts**

1 x **1097** 25.4 x 50.8 x 198.9 mm (1 x 2 x 7 13/16 in)

**Hardware**



1 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)



**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)




[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

**Wood Parts**

1 x 1096 25.4 x 50.8 x 254 mm (1 x 2 x 10 in)

**Hardware**

3 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)





#### Wood Parts

2 x **1089** 25.4 x 50.8 x 228.6 mm (1 x 2 x 9 in)

#### Hardware

2 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)



#### Wood Parts

1 x 1092 25.4 x 25.4 x 362 mm (1 x 1 x 14 1/4 in)

#### Hardware



2 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)




**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)


[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100



Inside and Underneath View





Inside and Underneath View

**Wood Parts**


4 x 0998 25.4 x 50.8 x 50.8 mm (1 x 2 x 2 in)

**Hardware**

4 x S2 #8 x 38.1 mm (#8 x 1-1/2 in)




Inside and Underneath View

**Wood Parts**



2 x 1093 25.4 x 50.8 x 88.9 mm (1 x 2 x 3 1/2")

**Hardware**

2 x S3 #8 x 63.5 mm (#8 x 2-1/2 in)



Rotated and Outside View



**Wood Parts**

1 x **1091** 15.9 x 136 x 588 mm (5/8 x 5 3/8 x 23 1/8 in)

**Hardware**


5 x **S1** #8 x 28.6mm (#8 x 1-1/8 in)





**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100



Rotated and Inside View

**Wood Parts**



1 x 1091 15.9 x 136 x 588 mm (5/8 x 5 3/8 x 23 1/8 in)

**Hardware**

5 x S1 #8 x 28.6mm (#8 x 1-1/8 in)


**KidKraft®**  
 MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)
[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
 1.800.933.0771  
 972.385.0100





#### Wood Parts

1 x **1090** 15.9 x 114.3 x 535.8 mm (5/8 x 4 1/2 x 21 1/16 in)

#### Hardware

3 x **S1** #8 x 28.6mm (#8 x 1-1/8 in)

4 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)



#### Wood Parts

2 x **1088** 15.9 x 101.6 x 246.6 mm (5/8 x 4 x 9 11/16 in)

#### Hardware


10 x **S1** #8 x 28.6mm (#8 x 1-1/8 in)



**KidKraft**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100




#### Wood Parts

- 2 x **1099** 25.4 x 25.4 x 308.1 mm (1 x 1 x 12 1/8 in)  
 2 x **1100** 25.4 x 25.4 x 478.9 mm (1 x 1 x 18 7/8 in)

#### Hardware


- 4 x **S11** #8 x 50.8 mm (#8 x 2 in)

**Hardware**

14 x (S37) #7 x 15.9 mm (#7 x 5/8 in)

**Other Parts**

1 x 9340730




#### Wood Parts

1 x **1103** (Midnight Raven) 25.4 x 25.4 x 320.9 mm (1 x 1 x 12 5/8 in)

#### Hardware

2 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)




#### Wood Parts

1 x **1103** (Midnight Raven) 25.4 x 25.4 x 320.9 mm (1 x 1 x 12 5/8 in)

#### Hardware

2 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)



#### Wood Parts

1 x 1102 15.9 x 130 x 358.9 mm (5/8 x 5 1/8 x 14 1/8 in)

#### Hardware


5 x S20 #8 x 34.9 mm (#8 x 1-3/8 in)



**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100



#### Wood Parts

1 x 1102 15.9 x 130 x 358.9 mm (5/8 x 5 1/8 x 14 1/8 in)

#### Hardware


5 x S20 #8 x 34.9 mm (#8 x 1-3/8 in)



**KidKraft**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

**Wood Parts**





1 x **1101** 25.4 x 88.9 x 308.1 mm (1 x 3 1/2 x 12 1/8 in)

**Hardware**

3 x **S20** #8 x 34.9 mm (#8 x 1-3/8 in)

**Other Parts**

3 x **P-U-510-STGY**



#### Hardware

4 x  #8 x 50.8 mm (#8 x 2 in)


#### Other Parts

2 x 

38



Complete this step twice

**Wood Parts**

- 2 x **1104** 31.8 x 79.4 x 667 mm (1 1/4 x 3 1/8 x 26 1/4 in)  
 2 x **1105** 31.8 x 79.4 x 667 mm (1 1/4 x 3 1/8 x 26 1/4 in)  
 2 x **1106** 31.8 x 31.8 x 920.1 mm (1 1/4 x 1 1/4 x 36 1/4 in)



**KidKraft®**  
 MADE FOR MAKE BELIEVE™


[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
 1.800.933.0771  
 972.385.0100

39



Complete this step twice



**Wood Parts**

2 x **1116** 15.9 x 76.2 x 355.6 mm (5/8 x 3 x 14 in)


**Hardware**

8 x **S1** #8 x 28.6 mm (#8 x 1-1/8 in)

40



Complete this step twice



#### Wood Parts

4 x **1117** 15.9 x 76.2 x 269.2 mm (5/8 x 3 x 10 5/8 in)

#### Hardware

16 x **S1** #8 x 28.6 mm (#8 x 1-1/8 in)




[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

41

Complete this step twice



**Wood Parts**

2 x 1115 15.9 x 76.2 x 317.5 mm (5/8 x 3 x 12 1/2 in)



**Hardware**

6 x S1 #8 x 28.6 mm (#8 x 1-1/8 in)



[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100




**Wood Parts**

- 1 x **1108** 15.9 x 85.7 x 184.2 mm (5/8 x 3 3/8 x 7 1/4 in)  
 1 x **1124** 15.9 x 85.7 x 168.3 mm (5/8 x 3 3/8 x 6 5/8 in)

**Hardware**



- 8 x **S1** #8 x 28.6 mm (#8 x 1-1/8 in)

43



**Hardware**

4 x  #8 x 28.6 mm (#8 x 1-1/8 in)




**Wood Parts**

- 1 x **1108** 15.9 x 85.7 x 184.2 mm (5/8 x 3 3/8 x 7 1/4 in)  
 1 x **1123** 15.9 x 85.7 x 168.3 mm (5/8 x 3 3/8 x 6 5/8 in)

**Hardware**




- 8 x **S1** #8 x 28.6 mm (#8 x 1-1/8 in)

45



**Hardware**

4 x  #8 x 28.6 mm (#8 x 1-1/8 in)

**Wood Parts**

1 x **1107** 25.4 x 50.8 x 939.7 mm (1 x 2 x 37 in)

**Hardware**



4 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)



**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100






#### Wood Parts

1 x 1107 25.4 x 50.8 x 939.7 mm (1 x 2 x 37 in)

#### Hardware



4 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)

**Wood Parts**

1 x **1109** 25.4 x 82.6 x 939.8 mm (1 x 3 1/4 x 37 in)

**Hardware**

2 x **S3** #8 x 63.5 mm (#8 x 2-1/2 in)



#### Wood Parts

1 x 1114 25.4 x 50.8 x 938.2 mm (1 x 2 x 36 15/16 in)

#### Hardware



4 x S3 #8 x 63.5 mm (#8 x 2-1/2 in)





**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100






Underneath View

**Wood Parts**

1 x 1112 25.4 x 50.8 x 650.8 mm (1 x 2 x 25 5/8 in)

**Hardware**

6 x S41 #8 x 22.2 mm (#8 x 7/8 in)



#### Wood Parts

1 x 1118 25.4 x 50.8 x 76.2 mm (1 x 2 x 3 in)

#### Hardware




2 x S2 #8 x 38.1 mm (#8 x 1-1/2 in)



**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

**Wood Parts**

1 x **1110** 25.4 x 55.5 x 938.2 mm (1 x 2 1/4 x 36 15/16 in)

**Hardware**

4 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)



2 x **S3** #8 x 63.5 mm (#8 x 2-1/2 in)




**KidKraft**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100



Do not attach, use  
for alignment only.





#### Wood Parts



1 x 1114 25.4 x 50.8 x 938.2 mm (1 x 2 x 36 15/16 in)

#### Hardware

4 x S3 #8 x 63.5 mm (#8 x 2-1/2 in)








Underneath View

**Wood Parts**

1 x 1113 25.4 x 50.8 x 618.2 mm (1 x 2 x 24 5/16 in)

**Hardware**

6 x S41 #8 x 22.2 mm (#8 x 7/8 in)




#### Other Parts

1 x 9340029




Underneath View



Note: Structure  
removed for clarity


Underneath View

**Hardware**

2 x  #7 x 15.9 mm (#7 x 5/8 in)




Underneath View




Note: Structure  
removed for clarity

#### Hardware

20 x  #7 x 15.9 mm (#7 x 5/8 in)



There could be some differences clearly, and the max number of screws are provided.



#### Hardware




10 x (S37) #7 x 15.9 mm (#7 x 5/8 in)



**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100



#### Wood Parts

1 x 1111 25.4 x 44.5 x 977.9 mm (1 x 1 3/4 x 38.5 in)

#### Hardware

2 x S3 #8 x 63.5 mm (#8 x 2-1/2 in)

2 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)





**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

## 60 Repeat Step 55 - 59 for the other roof



### Wood Parts

1 x **1111** 25.4 x 44.5 x 977.9 mm (1 x 1 3/4 x 38.5 in)

### Hardware

32 x **S37** #7 x 15.9 mm (#7 x 5/8 in)

2 x **S3** #8 x 63.5 mm (#8 x 2-1/2 in)

2 x **S15** #8 x 44.5 mm (#8 x 1-3/4 in)


### Other Parts

1 x **9340029**



[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100




#### Wood Parts

- 1 x 0938 50.8 x 365.1 x 372.3 mm (2 x 14 3/8 x 14 5/8 in)  
 1 x 0942 50.8 x 365.1 x 372.3 mm (2 x 14 3/8 x 14 5/8 in)

#### Hardware

- 1 x S3 #8 x 63.5 mm (#8 x 2-1/2 in)

**Wood Parts**

1 x **1119** 31.8 x 50.8 x 387.1 mm (1 1/4 x 2 x 15 1/4 in)

**Hardware**


2 x **S11** #8 x 50.8 mm (#8 x 2 in)



**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100

**Wood Parts**

- 1 x **1121** 15.9 x 38.1 x 206.4 mm (5/8 x 1 1/2 x 8 1/8 in)  
 2 x **1122** 15.9 x 38.1 x 133.4 mm (5/8 x 1 1/2 x 5 1/4 in)

**Hardware**


- 6 x **S1** #8 x 28.6 mm (#8 x 1-1/8 in)



**KidKraft®**  
 MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
 1.800.933.0771  
 972.385.0100

**Wood Parts**

1 x 1120 15.9 x 34.9 x 101.6 mm (5/8 x 1 3/8 x 4 in)

**Hardware**



3 x S1 #8 x 28.6 mm (#8 x 1-1/8 in)





**KidKraft®**  
MADE FOR MAKE BELIEVE™

[kidkraft.com](http://kidkraft.com)

[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
1.800.933.0771  
972.385.0100



Top View

**Hardware**

2 x (S1) #8 x 28.6 mm (#8 x 1-1/8 in)



3 x (S11) #8 x 50.8 mm (#8 x 2 in)


**KidKraft®**  
 MADE FOR MAKE BELIEVE™





[kidkraft.com](http://kidkraft.com)
[customerservice@kidkraft.com](mailto:customerservice@kidkraft.com)  
 1.800.933.0771  
 972.385.0100

66

Important: Use a handheld screwdriver  
and DO NOT overtighten




Rotated View

**Hardware**


6 x S37 #7 x 15.9 mm (#7 x 5/8 in)

**Other Parts**



|             |              |             |
|-------------|--------------|-------------|
| 1 x 9320382 | 2 x 52040302 | 1 x 9322282 |
| 1 x 9332608 | 1 x 9320881  | 1 x 3332609 |



Inside and Underneath View



Inside and Underneath View

**Wood Parts**

1 x 1103 (Pearl) 25.4 x 25.4 x 320.9 mm (1 x 1 x 12 5/8 in)

**Hardware**

2 x S15 #8 x 44.5 mm (#8 x 1-3/4 in)






2 x S37 #7 x 15.9 mm (#7 x 5/8 in)

**Other Parts**

1 x 9321691 1 x 9320889RD

1 x 9320888STGY

1 x 9320889STGY





#### Other Parts

1 x 9340307




1 x 9340308

1 x 9340309



#### Hardware

1 x (S0) #8 x 22.2 mm (#8 x 7/8 in)





#### Hardware

4 x (S0) #8 x 22.2 mm (#8 x 7/8 in)

#### Other Parts

2 x 9320157





#### Hardware

2 x (S0) #8 x 22.2 mm (#8 x 7/8 in)

#### Other Parts

1 x 9320157





#### Hardware

2 x (S0) #8 x 22.2 mm (#8 x 7/8 in)

#### Other Parts


1 x 9320157

**Hardware**

4 x (S0) #8 x 22.2 mm (#8 x 7/8 in)

**Other Parts**

1 x 9200769




#### Other Parts

|     |         |     |         |
|-----|---------|-----|---------|
| 1 x | 3750000 | 1 x | 3340023 |
| 4 x | 9341928 | 1 x | 9340031 |

[illegible]

# 3 EASY WAYS TO REGISTER YOUR PRODUCT 24/7

- 1) Scan this QR Code with your smartphone to complete your product registration directly from your phone:
- 2) Complete the registration online at: <https://www.kidkraft.com/pages/warranty>
- 3) Mail this completed form to: Backyard Kids, LLC DBA KidKraft  
317 S. Main St. Ann Arbor, MI 48104  
Make sure to include a copy of your proof of purchase



## KIDKRAFT Consumer Registration Card

|                              |                      |                                                                 |
|------------------------------|----------------------|-----------------------------------------------------------------|
| First Name                   | Initial              | Last Name                                                       |
| <input type="text"/>         | <input type="text"/> | <input type="text"/>                                            |
| Street                       |                      | Apt. No.                                                        |
| <input type="text"/>         |                      | <input type="text"/>                                            |
| City                         | State/Province       | ZIP/Postal Code                                                 |
| <input type="text"/>         | <input type="text"/> | <input type="text"/>                                            |
| Country                      | Telephone Number     |                                                                 |
| <input type="text"/>         | <input type="text"/> |                                                                 |
| E-Mail Address               |                      |                                                                 |
| <input type="text"/>         |                      |                                                                 |
| Model Number                 | Model Name           |                                                                 |
| <input type="text"/>         | <input type="text"/> |                                                                 |
|                              |                      | Model Number & Name example<br>F2XXXX KidKraft Item Description |
| Purchased From               | Date Purchase        |                                                                 |
| <input type="text"/>         | <input type="text"/> |                                                                 |
|                              |                      | MM / DD / YY                                                    |
| Serial Number (on ID Plaque) |                      | ID Plaque example                                               |
| <input type="text"/>         |                      |                                                                 |

Box #: \_\_\_\_\_ 1 of \_\_\_\_\_

Box #: \_\_\_\_\_ 4 of \_\_\_\_\_

Box # (Ex: BXXXX 1of 6)

Box #: \_\_\_\_\_ 2 of \_\_\_\_\_

Box #: \_\_\_\_\_ 5 of \_\_\_\_\_



Box #: \_\_\_\_\_ 3 of \_\_\_\_\_

Box #: \_\_\_\_\_ 6 of \_\_\_\_\_

For common questions or for information on ordering replacement parts:  
<https://www.kidkraft.com/pages/warranty>

**MADE IN CHINA**