



Four Cooking Functions
Choose from convection bake, broil, toast, and keep warm.



Compact Size
Easily fit a 9" pizza, four slices of bread, or a variety of other snacks and meals.



30-Minute Timer
The precise cooking timer features a stay-on function for longer baking tasks.



Included Rack and Pan
The included rack and bake pan fit perfectly in the toaster oven.



EvenToast Technology™
Consistent heating for evenly toasted bread.



EvenToast Technology™



Gray/Stainless Steel



Extra-Wide Viewing



Removable Crumb Tray



Gray/Stainless Steel
Find a fit for your kitchen with the dark gray exterior and stainless steel accents.



Extra-Wide Viewing
Keep a close watch on food while it bakes without opening the oven door.



Removable Crumb Tray
Easily remove food crumbs before they burn in the bottom of the oven.

BLACK+DECKER™ TO1705SG 4-Slice Toaster Oven, Easy Controls

Great for cooking snacks and whipping up appetizers fast! This toaster oven fits a 9" pizza or four slices of bread, and the simplified dial controls let you set the 30-minute timer and choose to bake, broil, toast, or keep warm. Plus, our exclusive EvenToast Technology™ delivers delicious and evenly done toast.

