


Installation Guide [How to replace new filter]




- 1. Loosen a screw.
- 2. Push the cabinet down and pull it out.



- 3. Turn the lever On/Off valve to stop water flow.
- 4. Twist the filter clockwise and pull downward to remove it.



- 5. Put the new filter and turn the filter counterclockwise.
- 6. Re-turn the lever of valve for allowing water to flow.
- 7. Push the botton of 11-month-timer.



- 8. Re-assemble cabinet
- 9. Screw the cabinet.

