


Using The Air Fryer Basket & Handle **B**



Attach Handle to Air Fryer Basket

1. Gently press the sides of the handle together
2. Insert ends in slots on the frying basket from the top and release in place
3. Rotate clip on top of handle until you hear a click



CAUTION: Use extra care not to touch the Air Fryer Basket (B) when attaching the Handle after cooking as Air Fryer Basket (B) will be HOT.

Remove Handle from Air Fryer Basket

1. Flip right side of clip up off of handle and rotate underneath
2. Gently press the sides of the handle together and lift off of basket

Placing The Baking Racks

Place the Baking Racks (D) on one of the 2 rails inside the appliance. Place on the lower rails for lower temperature and on higher rails for higher temperature.



NAME	DETAIL	FUNCTION
1	Display	Displays time/temperature
2	⌚ +/-	Increase/decrease cooking time
3	⏻	Switch on/off
4	↻	Rotation function (for accessories F/G/H)
5	Reheat	Reheat (pre-set)
6	💡	Light on/off
7	Pre-sets	Pre-set programs
8	⌚ +/-	Increase/decrease temperature
9	Preheat	Preheat

Start Cooking Without Preheating Air Fryer

- STEP 1** Place food in the appropriate accessory and carefully insert it in the air fryer.
- STEP 2** Select the preset cooking function.
- STEP 3** Adjust time and temperature to match your recipe
- STEP 4** Cooking will automatically begin after 5 seconds of inactivity

Start Cooking Using the Preheat Function

- STEP 1** Select the preset cooking function.
- STEP 2** Adjust time and temperature to match your recipe
- STEP 3** Press the Preheat button
- STEP 4** When the air fryer is preheated, it will beep 3 times and the display will instruct to ADD FOOD
- STEP 5** Carefully insert food into the air fryer
- STEP 6** Cooking will automatically begin after 5 seconds of inactivity

CAUTION: RISK OF FIRE!
Never use a cooking container filled with cooking oil or other hot liquids

CAUTION: RISK OF BURNS!
The product gets hot during and after use. Do not touch hot surfaces with bare hands. Wear oven mitts during use.

Sur la table

MULTIFUNCTIONAL AIR FRYER OVEN

13 QUART

QUICK START GUIDE

USING THE ACCESSORIES

	NAME	FUNCTION
B	Air Fryer Basket & Handle	Use to fry larger quantity of foods. Always place on the drip tray (C) inserted into the lowest rail.
C	Drip Pan	Use to collect oil and other residues during frying process.
D	Baking Racks	Use to dehydrate, fry crispy snacks and reheat food.
E	Rotisserie Stand	Use to place the accessory (F, G, H) when hot after cooking. CAUTION: Do not place the stand inside the oven.
F	Rotation Basket	Use to fry food more evenly. Use to prepare french fries and roasted dry fruits.
G	Skewers & Rack	Use to air fry / barbecue meat/fish/vegetables.
H	Rotisserie Spit Set	Use to air fry whole chicken/large pieces of meat. Force shaft lengthwise through the meat.
I	Rotisserie Holder/Handle	Use to place and remove the accessory (F, G, H).

Make sure the whole chicken/large pieces of meat fit into the appliance without making contact with the heating elements or side walls or door of the appliance when rotating.


CAUTION: RISK OF INJURY! Skewers and forks have sharp edges. Handle with care.




Scan here for bonus recipes and to watch how-to videos that will help you make the most of your air fryer. or go to www.mcappliances.us




Using The Rotation Basket **F**



Using The Rotisserie Spit Set **H**




Insert Rotisserie into Appliance **F G H**




Hold the assembled Rotisserie Bar at a slight angle with the right side higher than the left side and insert the left side of the Bar into the Rotisserie connection inside the appliance first. Then place the right end on to the bracket slot to secure.

Using The Rotisserie Stand **E**



Using the Skewers & Rack **G**



Using the Rotisserie Holder/Handle **I**

